



iMod DC Scene Module Installation

Switch-plate






Bell type push buttons only
Wire directly to QS iMod Scene module

LED INDICATOR




Button Linking:






To unlink a button: Repeat steps 2&3.

POWER SUPPLY WIRING




Scene Saving:




iMod DC Scene Module Installation

Switch-plate






Bell type push buttons only
Wire directly to QS iMod Scene module

LED INDICATOR




Button Linking:



To unlink a button: Repeat steps 2&3.

POWER SUPPLY WIRING



Scene Saving:

