Qwik-Switch Keyfob Installation



A Receiver can link up to 30 different buttons.
To unlink a button: Repeat steps 2&3.
To clear all links in a Receiver:
Hold the Reciever Link Button until the LED is ON solid (10 sec) then release.

TRANSMITTER:

Button Operation:
Press = ON/OFF/STOP DIMMING
Hold = DIM UP/DOWN

LED Indicator on button press:
1 Flash = Normal operation
2 Flashes = Battery Low

BATTERY REPLACEMENT



After replacing the battery, the LED will flash 3 times to indicate sucessfull power-up.

www.qwikswitch.co.za

Qwik-Switch Keyfob Installation

A Receiver can link up to 30 different buttons.
To unlink a button: Repeat steps 2&3.
To clear all links in a Receiver:
Hold the Reciever Link Button until the LED is ON solid (10 sec) then release.

TRANSMITTER:



Button Operation:
Press = ON/OFF/STOP DIMMING
Hold = DIM UP/DOWN

LED Indicator on button press:
1 Flash = Normal operation
2 Flashes = Battery Low

BATTERY REPLACEMENT



After replacing the battery, the LED will flash 3 times to indicate sucessfull power-up.

www.qwikswitch.co.za

Qwik-Switch Keyfob Installation

A Receiver can link up to 30 different buttons.
To unlink a button: Repeat steps 2&3.
To clear all links in a Receiver:
Hold the Reciever Link Button until the LED is ON solid (10 sec) then release.

TRANSMITTER:



Button Operation:
Press = ON/OFF/STOP DIMMING
Hold = DIM UP/DOWN

LED Indicator on button press:
1 Flash = Normal operation
2 Flashes = Battery Low

BATTERY REPLACEMENT



After replacing the battery, the LED will flash 3 times to indicate sucessfull power-up.

www.qwikswitch.co.za

Qwik-Switch Keyfob Installation



A Receiver can link up to 30 different buttons.
To unlink a button: Repeat steps 2&3.
To clear all links in a Receiver:
Hold the Reciever Link Button until the LED is ON solid (10 sec) then release.

TRANSMITTER:

Button Operation:
Press = ON/OFF/STOP DIMMING
Hold = DIM UP/DOWN

LED Indicator on button press:
1 Flash = Normal operation
2 Flashes = Battery Low

BATTERY REPLACEMENT

After replacing the battery, the LED will flash 3 times to indicate sucessfull power-up.

www.qwikswitch.co.za

Qwik-Switch Keyfob Installation



A Receiver can link up to 30 different buttons.
To unlink a button: Repeat steps 2&3.
To clear all links in a Receiver:
Hold the Reciever Link Button until the LED is ON solid (10 sec) then release.

TRANSMITTER:

Button Operation:
Press = ON/OFF/STOP DIMMING
Hold = DIM UP/DOWN

LED Indicator on button press:
1 Flash = Normal operation
2 Flashes = Battery Low

BATTERY REPLACEMENT



After replacing the battery, the LED will flash 3 times to indicate sucessfull power-up.

www.qwikswitch.co.za